




September 24, 2022

Correct Blower

Beam Or Leg Frame Install



Only Use the Given Impeller Configurations to Insure Blower Optimization



Make CarWashing Easy

TECHNICAL BULLETIN

PROPER INSTALL


Follow all steps to properly install the Correct Blowers either on the Beam or on the Leg Frame. Only use the given Impeller Options per position on the Frame to ensure Blower optimization.

IMPORTANT: Torque U-Bolts to 57 ft-lb. DANGER: Always Shutoff All Power to Conveyor and/or Equipment Before Starting Any Install, Maintenance, Service or Repairs. Failure to do this may result in personal injury, death, and/or dismemberment. **BEAM INSTALL – MOTOR SIDE** Impeller Options DO NOT OVERTIGHTEN **U-BOLTS** MAX TORQUE: 57 ft-lb Counterclockwise Clockwise Mammoth 15 HP Mammoth 15 HP Blue Impeller **Grey Impeller** Part # 10012464 Part # 10012463 15 HP 15 HP Green Center Impeller Red Center Impeller Part # 10008892 Part # 10008893 10 HP 10 HP Blue Center Impeller Blue Center Impeller Part # 20003310 Part # 20003311

Sonny's CarWash

Questions? Call Sonny's Technical Support at 800-327-8723 or email sonnys-support@sonnysdirect.com

Correct Blower Beam or Leg Frame Install September 24, 2022





Questions? Call Sonny's Technical Support at 800-327-8723 or email sonnys-support@sonnysdirect.com

This document is confidential and proprietary to SONNY'S and cannot be used, disclosed, or published without prior written consent. Content, prices, and availability subject to change without notice. All brand names, trademarks or registered trademarks are the property of their respective owners.







Questions? Call Sonny's Technical Support at 800-327-8723 or email sonnys-support@sonnysdirect.com